

Part List

- mechanical -

Xperia Z1™

C6902, C6903, C6906, L39h

1277-9817 Rev 1



CONTENTS



1 Part List

The following parts are available for order in ‘E-star’.

The ‘E-star’ name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual 1220-1333).

Designation	Part No.	RLC	Part	Location
Adhesive Earspeaker	1272-0782	C		
Adhesive FPC Relay Bottom	1273-9725	C		
Adhesive WP Audio Jack	1272-0161	C		
Adhesive WP Camera Key	1272-0111	C		
Adhesive WP Cover Rear	1272-0383	C		
Adhesive WP Loudspeaker	1272-0243	C		



Designation	Part No.	RLC	Part	Location
Adhesive WP Main Frame	1272-0163	C		
Adhesive WP Side Key	1272-0106	C		
Adhesive WP Window Back	1272-0690	C		
Battery	1271-9084	B		
BT + WLAN Flex Antenna	1271-7548	C		
Camera	1271-4830	B		
Camera Holder	1272-0235	C		
Camera Key Camera Key Black Camera Key Purple Camera Key White	 1272-0716 1274-9007 1273-9705	C		



Part List (mech)

Designation	Part No.	RLC	Part	Location
Chat Camera	1272-0870	C		
Chat Camera Holder	1272-0198	C		
Core Unit Label	1276-1828	C		
Cushion 1st Mic	1272-0159	C		
Cushion 2nd Mic	1272-0379	C		
Ear Speaker	1275-9546	C		
FPC Assembly Audio Jack	1270-6398	C		
FPC Assembly Charger	1270-6403			

Designation	Part No.	RLC	Part	Location
FPC Assembly Mic	1270-6400	C		
FPC Assembly Relay (RoW) FPC Assembly Relay (C6906)	1270-6401 1276-6631			
Front Cover Front Cover RoW Black Front Cover RoW Purple Front Cover RoW White	 1276-5214 1276-5216 1276-5215	A		
Gasket Charger	1276-5058	C		
Gasket Side Key	1272-0103	C		
Holder Magnetic Charger Connector	1272-2740	C		
Liquid indicator	1275-3307	C		
Loudspeaker	1267-9538	C		



Designation	Part No.	RLC	Part	Location
Loudspeaker Holder	1272-0238	C		
Magnetic charger connector Magnetic charger connector Black/Purple Magnetic Charger Connector White	1272-1417 1275-9331	C		
Main Frame Assy Main Frame Assy Black Main Frame Assy Purple Main Frame Assy White	1272-0048 1274-9002 1273-9702	B		
PBA Cellular Sub PBA Cellular Sub C6906 PBA Cellular Sub RoW	1276-8165 1271-2428	C		
PBA WLAN Sub	1271-2437	C		
Plate Contact RF A	1272-0337	C		
Power Key	1272-0089	C		



Part List (mech)

Designation	Part No.	RLC	Part	Location
Rear Cover Assy Rear Cover Assy Black Rear Cover Assy Purple Rear Cover Assy White	 1272-0350 1274-8999 1273-9712	C		
RF Cable A	1272-3938	C		
RF Cable B	1272-3918	C		
Screw 3.5x1.4	1248-2355	C		
SD Cap SD Cap Black SD Cap Purple SD Cap White	 1272-0134 1274-9010 1273-9708	C		
Sheet Battery	1277-0900	C		
Sheet Conductive Charger FPC	1273-9721	C		
Sheet Conductive Relay FPC	1273-9719	C		



Part List (mech)

Designation	Part No.	RLC	Part	Location
Sheet Thermal A	1272-0035	C		
Sheet Thermal B	1273-9723	C		
Sheet WP 2nd Mic	1272-0376	C		
Sheet WP Check	1272-0157	C		
Shield Camera	1272-0230	C		
SIM Cap SIM Cap Black SIM Cap Purple SIM Cap White	 1272-0142 1274-9012 1273-9710	C		
SIM Tray	1272-5201	C		
Speaker Panel Speaker Panel Black Speaker Panel Purple Speaker Panel White	 1272-0699 1274-9049 1273-9716	C		



Part List (mech)

Designation	Part No.	RLC	Part	Location
Tray Core Unit Label	1272-0043	C		
USB Cap USB Cap Black USB Cap Purple USB Cap White	 1272-0117 1274-9008 1273-9706	C		
USB Holder	1272-0200	C		
Vibrator	1276-5086	C		
Window Back Window Back RoW Black Window Back RoW Purple Window Back RoW White	 1276-6948 1276-6949 1276-6950	B		
Volume Key Volume Key Black Volume Key Purple Volume Key White	 1272-0713 1274-9006 1273-9704	C		



2 Revision History

Rev.	Date	Changes / Comments
A	2013-09-05	Initial release